## Installation instructions For set # 16.3123 06-11 Honda Civic SI Rear Lower Trailing Arm Bushings And Lower Knuckle Bushings



C 2014 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle. Wheel alignment is almost always disturbed when suspension components are removed or replaced. It is recommended that you have the alignment checked on your vehicle at a qualified alignment shop. Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list. Prior to installation, make sure that your car is in excellent mechanical condition and that there are no suspension or steering related problems. This part has been designed to work only with a car that is in good state of repair. No matter how carefully we design our parts, this is one area we have no control over and cannot be held responsible.

## Parts list: 16.3123

- 2 ea 03P03542 (Front POS. Outer Front Bushing).
- 2 ea 03P03543 (Front POS. Inner Bushing).
- 2 ea 03P03544 (Front POS. Outer Rear Bushing).
- 2 ea 03P03545 (Rear POS. Bushing).
- 2 ea 15.10.613.39 (1.000" O.D. x .500" I.D. x 1.960" LG. Sleeve for rear position).
- 2 ea 03P03546 (Rear Knuckle Front POS. Bushing).
- 2 ea 03P03547 (Rear Knuckle Front POS. Inner T/W).
- 2 ea 15.10.492.39 (1.000" O.D. x .563" I.D. x 1.817"LG. Sleeve For Rear Knuckle Front Position).
- 2 ea 03P03548 (Rear Knuckle Rear POS. Bushing).
- 2 ea 03P03549 (Rear Knuckle Rear POS. Inner T/W).
- 2 ea 15.10.574.39 (1.000" O.D. x .563" I.D. x 2.000"LG. Sleeve For Rear Knuckle Rear Position).



in this kit. DO NOT REMOVE BUSHINGS FROM UPPER CONTROL ARM!



Use a paint marker to matchmark the adjustment cam bolt in two places both sides before removing rear trailing arm from vehicle.



Clamp one end of the flanged pin in a vice. using an adjustable wrench and a pry bar, SLOWLY ROTATE (15° to 30° max) flanged pin back and forth prying up at the same time. The pin is press fit into a inner sleeve. This is not easy but it will come out. You only need to remove the one flanged pin from the inner sleeve, leave the other-side flanged pin pressed in.



Do not remove outer metal shell from trailing arm, it must be reused for this bushing set to work.



To remove the remaining flanged pin and inner sleeve, evenly apply heat to inside of sleeve. This heat will break the bond and the flanged pin and the sleeve will come out. At no time should there be flames from burning rubber, only steady heat.

> 20/AUG/15 BRH ECN 13065

17P17619 Pg. 1 of 3

## Installation instructions For set # 16.3123 06-11 Honda Civic SI Rear Lower Control Arm Bushings And Lower Knuckle Bushings



To remove the rear position rubber bushing, evenly apply heat to outside of metal shell. This heat will break the bond and the old rubber will come out. At no time should there be flames from burning rubber, only steady heat.



© 2014 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.





To remove the bushings from the rear knuckle you must first remove the flanges from the factory aluminum shells.



Chisseling under the aluminum flange will start to crack the flange from the shell leaving only the bonded rubber holding the flange in place. Use a razor knife to cut the remaning rubber.



I.D. of rear knuckle front position is Ø1.693" (43mm). Using a hydraulic press, properly support knuckle and slowly press out the rubber bushing with bonded outer aluminum shell.







17P17619 Pg. 3 of 3 20/AUG/15 BRH ECN 13065