OPEN FIRST!!

Parts list for Master set # 2.18104

55-75 JEEP CJ-5 & CJ-7

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front leaf spring & shackle bushing set: 2.2101

6 - 2001 bushings.

6 - 15.10.26.39 (.562" O.D.x.437" I.D.x1.845" LG. sleeve)

1 - 17040 installation instructions.

Rear leaf spring & shackle bushing set: 2.2101

6 - 2001 bushings.

6 - 15.10.26.39 (.562" O.D.x.437" I.D.x1.845" LG. sleeve)

1 - 17040 installation instructions.

Body mount set: 2.4101 14 - 4048 bushings.

Tie-rod boot set: 9-13101 (2ea)

4 - 13001 tie-rod boots

Grease: Formula 5 Prelube.3 - 9.11101 grease tubs.
(See our catalog for more details).



© 2007 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Additional parts available for your vehicle:

Shock boots

fits most aftermarket shocks (2 per set) set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.