

OPEN FIRST!!

Parts list for Master set # 3-18106

82-01 Chevy S-10 / GMC S-15 2WD



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2002 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Note: It is recommended that this set be professionally installed if you are unfamiliar with this type of work, and a factory service manual be purchased prior to performing any work on your vehicle for proper disassembly, reassembly and torque specs. These instructions are intended for bushing removal and install of Energy Suspension polyurethane bushings, once you have removed the factory component from your vehicle.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and parts list **before you start**.

Transmission mount set: 3.1108

- 1 - 1036 mount.
- 1 - 15.08.10.39 (backing plate).
- 2 - 15.03.48.39 (7/16" lock washer).
- 4 - 15.03.42.39 (7/16" flat washer).
- 2 - 15.05.30.39 (7/16"-14 x 1" bolt).
- 1 - 17112 installation instructions.

Front end control arm bushing set: 3.3162

- 2 - 3008 lower control arm bushings (rear position).
- 2 - 15.10.10.39 (3/4"O.D. x 1/2" I.D. x 2.40" sleeve).
- 2 - 15.02.02.39 "B" shells.
- 2 - 3224 lower control arm bushings (front position).
- 2 - 15.10.08.39 (3/4"O.D. x 9/16" I.D. x 3.00" sleeve).
- 2 - 15.02.11.39 "K" shells.
- 4 - 3293 upper control arm bushings.
- 4 - 15.10.50.39 (7/8"O.D. x 11/16" I.D. x 1.80" sleeve).
- 4 - 15.02.16.39 "P" shells.
- 1 - 17019 installation instructions.

Rear leaf spring and shackle bushing set: 3.2129

- 8 - 2004 spring bushings.
- 2 - 2109 frame shackle bushings.
- 2 - 2110 thrust washers.
- 6 - 15.10.08.39 (3/4"O.D. x 9/16" I.D. x 3.00" sleeve).
- 1 - 17060 installation instructions.

Body mount set: 3.4131

STD and Extended Cab pickup.

Must reuse all factory hardware.

- 4 - 4067 bushings (top, position 1 & 2).
- 8 - 4068 bushings (bottom, all positions).
- 4 - 4085 bushings (top, position 3 & 4).
- 1 - 17045 installation instructions

Parts list continued:

Front greaseable sway bar bushings and end link set: (1" bar): 9.5161

- 2 - 5340 bar bushings (1"bar).
- 2 - 15.12.06.39 greaseable brackets.
- 4 - 15.03.23.39 (.702"O.D. x .402" I.D. washer)
- 1 - 17145 installation instructions

End Link kit: 9.8119

- 8 - 4806 end link grommets.
- 8 - 15.03.01.39 cupped washers.
- 2 - 15.10.24.39 (9/16"O.D. x 3/8" I.D. x 3.375" sleeve).
- 2 - 15.05.05.39 (3/8"-16 x 7-1/2" bolt)
- 2 - 15.07.01.39 (3/8"-16 nut)
- 1 - 17039 installation instructions

Tie rod boot set:

- 4 - 13001 tie rod boots.

Grease:

- 8 - 9.11101 grease tubs.

Additional parts available for your vehicle:

Shock boots

fits most aftermarket shocks (sold in pairs)
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see our catalog at your place of purchase.

17207

Updated 1/30/2013 KLB
1/09/97 KN