



HIGH PERFORMANCE MUFFLER INSTALLATION INSTRUCTIONS

**D660-0360, 3000, 3028, 3181, 3182, 3183, 3200, 3251, 3252,
5251, 5255, 5351, 6350, 7350, 7410, 7500, 8400, and 8600**

Please Note: Some mechanical skill is required to install this muffler. If you are not familiar with this procedure, we strongly recommend that you arrange for a qualified BMW repair facility to perform this installation.

INSTALLATION:

For ALL Vehicles:

1. Remove the original muffler following the recommended BMW procedure.
2. Carefully inspect all hardware associated with the muffler including but not limited to nuts, bolts, sealing rings, hangers etc. Replace any necessary parts.
3. Install the DINAN High Performance Muffler following the recommended BMW procedure.
4. Check for clearance. The muffler and pipes should not touch anything.

NOTE: There is some adjustability when installing the muffler.

For 328i(s) ONLY:

The BMW 328i(s) utilizes a vacuum mechanism to actuate a “butterfly” valve in one tip of the stock OEM muffler. This vacuum line must be plugged to prevent a vacuum leak which will adversely affect the performance of your vehicle.