



## FREEFLOW EXHAUST SYSTEM INSTALLATION INSTRUCTIONS

**Part Number:** D660-4604

**Applications:** 2001-05 M3

---

### PARTS LIST

I	Freeflow Exhaust Assembly
I	Installation Hardware Pack

---

#### **Please Note:**

- Thank you for purchasing a Dinan High Performance Muffler! Some mechanical skill is required to install this muffler. If you are not familiar with this procedure, we strongly recommend that you arrange for a qualified BMW repair facility to perform this installation.
- Do not work on vehicles supported by a jack only. Use secure jack stands!
- For best results, we recommend that this muffler be used with the appropriate Dinan software for your vehicle. Please contact your Dinan representative for details.

If you encounter any difficulties during installation, or if these instructions are not clear to you, please call Dinan Engineering's Technical Support Staff @ (408) 779-8584.

#### **INSTALLATION:**

1. Remove the stock muffler following recommended BMW procedure.
2. The installation of the Dinan muffler is simply the reverse of removal. Please take note to:
  - Examine the rubber mounts for damage. Replace as necessary.
  - Examine the exhaust gaskets for damage. Replace as necessary.
  - Attach the Dinan muffler to the exhaust pipes using the bolts and locknuts supplied in the kit. Do not reuse the stock hardware at this connection.
  - The hangers are slotted to allow some adjustability. Be sure to center the exhaust tips in the openings in the rear bumper, with least 1/2" of clearance above the exhaust tips to the rear bumper. Also verify that both sets of exhaust tips are level.

NOTE: Upon initial startup after muffler installation, the exhaust may sound strange. This is a normal occurrence, as the internal muffler packing has not settled into position. Perform moderate driving for several miles to remedy this situation.