

E4-WM5-Y374A00 MOUNTING INSTRUCTION



IMPORTANT! READ THIS FIRST

Installation of shock absorbers requires special tools and expert knowledge. Accordingly, installation of all BILSTEIN products must be performed by a qualified suspension specialist.

Always use a chassis hoist for the installation of BILSTEIN products and make certain that the raised vehicle is securely attached to the hoist and/or supported to prevent the vehicle from slipping, falling, or moving during the installation process.

If you choose to install any BILSTEIN product without the necessary special tools, expertise or chassis hoist, you may subject yourself to the risk of serious bodily injury or death. If you elect not to use a chassis hoist, at least make sure the vehicle is on level ground, that all tires on the ground during installation are blocked to prevent movement, that at least two tires are on the ground at all times, and that adequately secured safety stands (jack stands) are used to support the chassis. **NEVER** get under the vehicle until you have checked to make sure all of these steps are performed.

E4-WM5-Y374A00 MOUNTING INSTRUCTION



1. Disassemble rear shock according to vehicle manufacturer's procedures.
2. On the new Bilstein shock absorber, install the provided mount parts in the order as shown in the diagram below.
3. Tighten upper nut to 25 Nm (19 lb/ft). Do not re-use original fasteners.
4. Tighten lower nut to 75 Nm (55 lb/ft). Do not re-use original fasteners.

