OPEN FIRST!!

Parts list for Master set # 3-18101



Parts list:

Energy Suspension recommends that you read over all the installation instructions and parts list before you start.

Font end control arm bushing set:(must reuse all metal parts)

- 2 3090 lower control arm pivot bushing rear position
- . 2 15.107 (7/8"O.D. x 5/8"I.D. x 3.860" sleeve)
- 2 3091 lower control arm pivot bushing front position
- 2 15.108 (7/8"O.D. x 5/8"I.D. x 2.960" sleeve)
- 4 3092 upper control arm pivot bushing
- 1 17019 installation instructions

Rear leaf spring and shackle bushing set:

- 8 2101 spring bushing
- 4 2102 frame shackle bushing
- 6 15.008 (3/4"O.D. x 9/16"I.D. x 3.00"
- 1 17040 installation instructions

Body mount set: Must reuse all factory hardware.

Std. cab use the following.

- 4 4076 bushing (top)position #1 & #2
- 2 4077 bushing (top)pos. #4(rearmost loc.)
- 2 4078 bushing (bottom)pos. #1
- 4 4079 bushing (bottom)pos. #2 & #4(rearmost loc.)
- 1 17037 installation instructions

Extended cab models use the following bushings in addition to the bushings above.

- 2 4076 bushing (top)position #3
- 2 4079 bushing (bottom)position #3 use 17037 installation instructions

Parts list continued:

Front swaybar bushing and endlink set (32mm bar):

- 2 5023 bar bushing (reuse factory bracket)
- 8 4806 endlink grommets
- 8 15.301 cupped washers
- 2 15.047 (9/16"O.D. x 3/8" I.D. x 4.500" sleeve)
- 2 15.506 (3/8"-16 x 8-1/2" bolt) 2 15.701 (3/8"-16 nut)
- 1 17039 installation instructions

Tie rod boot set:

4 - 13001 tie rod boots

Grease:

2 - 9.11101 grease tubs

Additional parts available for yor vehicle:

Shock boots

fits most aftermarket shocks (2 per set) set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see our catalog at your place of purchase.