<u>OPEN FIRST!!</u>

Parts list for Master set # 3.18102

Parts list:

Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list **before you** start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front leaf spring bushing set:

- 4 2006 main eve bushings
- 2 15.009 (3/4"O.D. x 9/16"I.D. x 3.500 sleeve)
- 4 2007 rear spring eye bushing 2 15.028 (5/8"O.D. x 7/16"I.D. x 3.500 sleeve)
- 4 2008 frame shackle bushing
- 15.028 (5/8"O.D. x 7/16"I.D. x 3.500 sleeve)
- 1 17010 installation instructions
- 1 17040 installation instructions

Rear leaf spring bushing set:

- 12 2004 spring bushings
- 6 15.008 (3/4"O.D. x 9/16"I.D. x 3.000 sleeve)
- 1 17040 installation instructions

Body (cab) mount set:(must reuse factory metal cups and hardware)

- 6 4067 bushing top
- 6 4068 bushing bottom
- 1 17023 installation instructions

Complete front swaybar bushing set (1-1/4" bar):

- 2 5032 bushings
- 2 15.018 (1"O.D. x 3/4"I.D. x 1.75" sleeve)
- 4 4901 grommets
- 1 17039 installation instructions

Tie-rod boot sets:

4 - 13007 tie-rod boot set

Grease:

- 1 9.11101 grease tub
- 1 9.11102 grease pack



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2007 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Additional parts available

Transmission mount (2 per set) 1981-84 Transmission mount 3-1106

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.