

OPEN FIRST!!

Parts list for Master set # 3.18104



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2007 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

GM 4 x 4 tranny mount set: 3.1106

- 2 - 1023 upper mount
- 2 - 1024 lower mount
- 2 - 15.10.188.39 (7/8"O.D. x 9/16" I.D. x 1.875" sleeve)
- 2 - 15.08.12.39 "U" bent bracket
- 2 - 15.03.35.39 (rectangle plates)

Front leaf spring bushing set (O.E.M.): 3.2105

- 4 - 2006 main eye bushings
- 2 - 15.10.09.39 (3/4"O.D. x 9/16" I.D. x 3.500 sleeve)
- 4 - 2007 rear spring eye bushing
- 4 - 2008 frame shackle bushing
- 4 - 15.10.28.39 (5/8"O.D. x 7/16" I.D. x 3.500 sleeve)
- 1 - 17010 installation instructions
- 1 - 17040 installation instructions

Rear leaf spring bushing set(O.E.M.): 3.2106

- 12 - 2004 spring bushings
- 6 - 15.10.08.39 (3/4"O.D. x 9/16" I.D. x 3.000 sleeve)
- use 17040 installation instructions

Body (cab) mount set:(must reuse factory metal cups and hardware): 3.4103

- 2 - 4008 bushing
- 2 - 4009 bushing
- 2 - 4010 bushing
- 2 - 4059 bushing
- 4 - 4011 bushing
- 6 - 15.03.05.39 (1/2" flat washer)
- 2 - 15.05.11.39 1/2" x 5" bolt
- 1 - 17011 installation instructions

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Parts list continued:

Complete greasable front swaybar bushing set: 3.5180

- 2 - 5354 bushing (1-1/4" I.D.)
- 2 - 5352 bushing (1-1/16" I.D.)
- 2 - 15.12.20.39 bushing bracket
- 4 - 15.03.23.39 washers
- 2 - 15.10.18.39 (1.00"O.D. x 3/4" I.D. x 1.75 sleeve)
- 4 - 4901 bushing
- 1 - 17039 installation instructions
- 1 - 17145 installation instructions

Tie-rod boot sets: 9.13101

- 4 - 13001 tie-rod boot set

Grease:

- 1 - 9.11101 grease tub
- 1 - 9.11102 grease pack

Additional parts available:

Transfer case torque mounts

for 1973-75 vehicles only set # 3.1107

Shock boots

fits most aftermarket shocks (2 per set)
set # 9.8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17182

9/APR/07 BRH
Rev. 12/20/2013 KLB