

Instructions

Gearbox Bushing Insert

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application - VW and Audi Platform
 - Various models
 (Refer current catalogue listing)

Install Guide

1. Raise vehicle evenly and safely support.

Never rely on a Jack only

2. Loosen and remove the bushing centre bolt - as per image below.

3. Confirm bushing is in reasonable condition prior to pushing in Insert.

4. Check your engine mount design against image below - this product is suited to the LH image (early vehicles). - refer catalogue for other shape.

5. Apply the supplied grease to insert fingers - to help with fitment.

6. Place the supplied large washer over the OE bolt,
 Then place the smaller washer over the OE bolt (on top of the large washer).

7. Bolt up to vehicle - tighten bolt.
 The smaller washer will sit inside insert.

Contents - 1x insert 91103
 - 1x washer 38mm OD
 - 1x washer 83mm OD
 - Grease

Check OE bushing design - this kit will suit early bushing



UP TO MID 2008



FROM MID 2008 ON



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.