

Instructions Performance Pitch-Stop Mount

This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application - Audi A3 Mk2
- Audi S3 Mk2
- VW Golf Mk5 & 6
- Skoda Octavia Mk2

Always refer catalogue for complete vehicle listing

WHITELINE Performance Pitch-Stop Mount is designed to reduce engine torque-twist - ultimately improving power transfer to the wheels and improving gear shifts.

- Start by raising car evenly and safely support.

Never rely on Jack stands only

Contents - 1x complete mount
- 2x M10 bolts
- 2x M10 small washers
- 1x large flat washer
- Poly bushings
- 1x inner steel tube - stepped.



- Proceed to un-bolt OE mount.
- remove the 2x M10 bolts and rear M14 bolt.

The rear M14 bolt will be re-used.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions Performance Pitch-Stop Mount

This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.



- Bolt up new mount as per below image.

Use new M10 bolts with washers
- tighten to 50 Nm

- tighten M14 bolt to 120Nm



- Note stepped inner tube
- Place supplied large flat washer here.
- Road test vehicle.
- Re-check all bolts after 100kms

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.