

D100-0939 SPRING SET; G42 M240i xDRIVE

INSTALLATION NOTES

PLEASE READ BEFORE BEGINNING INSTALLATION

Please refer to the part number printed on each spring to determine the correct installation location:

- D100-0890 = Front Spring
- D100-0892 = Rear Spring

For best results, we recommend installation of the companion handling kit, p/n D193-0121.

Alignment:

- An alignment is required after installation.
- All Dinan suspension alignments are done with full fuel tanks and no weight inside the vehicle.
- Specifications are as follows:

| FRONT: | Setting | Tolerance |
|-----------|---------|-----------|
| Camber | -1.0° | ± 0.42° |
| Caster | 7.7° | ± 0.5° |
| Total Toe | 0.27° | ± 0.07° |
| REAR: | | |
| Camber | -1.5° | ± 0.08° |
| Total Toe | 0.27° | ± 0.07° |

If you encounter any difficulties during the installation, or if these instructions are not clear to you, please call Dinan's Technical Support Staff @ (800) 341-5480.

Happy Motoring!

INS100-0939 Rev. 7/2/24