OPEN FIRST!! ENER



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts List for Master set # 5-18117

© 2010 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

Note: It is recommended that this set be professionally installed if you are unfamiliar with this type of work, and a factory service manual be purchased prior to performing any work on your vehicle for proper disassembly, reassembly and torque specs.

5.3137 Front Control Arm Bushing Set:

- 4 3460 Upper Control Arm
- 2 3461 Lower Control Arm Front Position
- 2 3462 Lower Control Arm Rear Position
- 4 -15.10.553.39 (1.00"o.d. X .640"i.d. X 4.090"L)
- 1 17458 Instructions

5.2115 Rear Leaf Spring Set:

- 4 2614 Spring Eye Front
- 2 15.10.555.39 (1.00"o.d. X .563"i.d. X 3.00"L)
- 4 2615 Spring Eye Rear
- 2 15.10.276.39 (.875"o.d. X .563"i.d. X 3.00"L)
- 4 2613 Upper Shackle Bushing
- 2 15.10.543.39 (.875"o.d. X .563"i.d. X 3.485"L)
- 1 17040 Instructions

5.5164 Front sway bar bushing set:

- 2 5786 34mm
- 2 5794 36mm
- 4 8084 End Links

NOTE: You will need to measure your sway bar, this vehicle may have a 34mm or 36mm sway bar.

5.10103 Rack & pinion bushing set:

- 4 2610 bushing
- 1 17459 instructions

5.6111 Front spring isolator set:

2 - 6242 coil spring isolator, upper

5.6112 Front lower bump stop set:

2 - 6243 bump stop