



**INSTRUCTION SHEET
FOR 32 AMP REGULATORS
201122 or 201122B**

1. Remove the original regulator.
2. Measure the output lead on the original regulator. Cut to length and terminate the output lead on your new ACCEL regulator.
3. Install ACCEL regulator in the same location as original regulator.
4. Connect plug into crankcase.
- 5.* Connect the output lead to the AUX (silver) terminal on the 30 amp main circuit breaker.

***NOTE:** Original regulator output lead may have been connected to the BATT (copper) terminal. You **must** connect the ACCEL regulator output lead to the AUX terminal (silver).

Printed in U.S.A.

693773