






# MISHIMOTO

MAX ACCEPTABLE STUD LENGTH:

MEASURE CURRENT WHEEL NUTS (TYPE, SIZE, AND LENGTH)  
AND STUDS TO ENSURE FITMENT BEFORE INSTALLATION.



FOR QUESTIONS OR ASSISTANCE WITH YOUR MISHIMOTO PRODUCT, CONTACT US AT 1.877.GOMISHI OR [SUPPORT@MISHIMOTO.COM](mailto:SUPPORT@MISHIMOTO.COM)