




Vehicle Application:  
 Make: **Chevrolet**  
 Model: **Corvette StingRay C7**  
 Year: **2014-2017**  
 Engine: **6.2L**

**EXPLODED VIEW**



| Item      | QTY. | P/N   | Discription                         |
|-----------|------|-------|-------------------------------------|
| A         | 1    | 1129  | Air Filter                          |
| B         | 1    | 15073 | Plenum                              |
| C         | 1    | 15074 | Box                                 |
| D         | 1    | 15072 | Tube                                |
| E         | 2    | 6047  | M4 screws                           |
| F         | 1    | 6111  | Filter Minder plug                  |
| G         | 2    | 14064 | 3/8" Machined Fitting               |
| H         | 1    | 3149  | Step Hose                           |
| I         | 1    | 4006  | #64 Clamps                          |
| J         | 1    | 3200  | 4.5" Hump Hose                      |
| K         | 3    | 4014  | #72 Clamps                          |
| L         | 4    | 6100  | M6x20mm                             |
| M         | 4    | 8047  | Rubberized Washers                  |
| Not shown | 1    | 6116  | 3/8-16 Hex drive bolt (Grand Sport) |

**TOOLS REQUIRED**

- 10mm Ratchet & Socket
- 8mm nut drive
- Allen key
- Needle nose
- Phillips Screwdriver
- Pliers

**WARNING:** FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE SYSTEM, ENGINE AND COMPONENTS!!!  
**\*Do not attempt to install the intake system while the engine is hot.**  
 Severe burn could result from touching hot engine components!

Report any defective or missing parts to the authorized Injen dealer you purchased this product from. Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation, please contact your Injen Technology dealer. Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

A Limited Lifetime Warranty to the original purchaser against defects in material and workmanship on all Injen intake systems excluding the filter element. Any and all warranty coverage is limited to the repair or replacement of the defective part only, at Injen Technology's discretion. The warranty does not cover incidental or consequential damages, nor does it cover the cost of installation or removal of the defective part or its replacement. Proof of purchase is required.

# Instruction Manual P/N:EVO7202

Injen intake systems are street legal in most states unless the state is adopting to California Emissions standards. States that have adopted California emission standards include: Arizona, California, Connecticut, District of Columbia, Maine, Maryland, Massachusetts, New Jersey, New Mexico, New York, Oregon, Pennsylvania, Rhode Island, Vermont, and Washington. These states will require an California Air Resource Board Executive Order Number (CARB E.O.) for the legal use of an Injen intake system in your vehicle for use on public roads or highways. These vehicle will be considered "Legal in California only for racing vehicles competition use only, which may never be used upon a public street or highway. **Please keep your factory air box assembly for any future use.**

The SuperNano-Web filter media is a dry synthetic media that outperforms the competition. The media itself is a proprietary base blend of synthetics and cellulose. Cellulose fibers are larger than synthetic fibers, and have larger spaces between the fibers, causing contaminants to load in the depth of the media and plug the airflow path. This creates higher restriction levels and less capacity. The synthetic fibers in the SuperNano-Web media are submicron in diameter and have small interior fiber spaces, which result in more contaminants being captured on the surface of the media. This can help keep restriction levels low as the filter loads with dirt and containments



The image block contains the Injen Technology logo on the left. To the right is a large 3D perspective view of the SuperNano-Web filter media, showing its pleated structure and the fine synthetic fibers on top. Below the logo are two side-by-side microscopic images: the left one shows 'Existing media without Injen SuperNano-Web Technology' with large, irregular fibers and significant gaps; the right one shows 'Superior Injen SuperNano-Web Technology' with a much denser, more uniform web of fibers. At the bottom right of the image block is a spider icon and the text 'A New Generation of Filters Designed to perform and filter like no other' and 'INJEN SuperNano-Web Technology'.

If you look at the picture to the left, you can see the Nano-fiber web on top of our base media. That web, or Super-Nano-Web as we like to call it, helps trap smaller particles and protect your engine.

## **To Clean your filter:**

Carefully remove the filter from the housing. Once removed, wipe down the housing using a clean shop towel, being careful not to knock any dirt and/or debris in the air inlet. Your filters can be cleaned by carefully vacuuming the filter media from the dirty side, or by holding the filter with one hand and carefully blowing the filter media at a 45-degree angle from the clean side using low-pressure shop air (15-20 lbs. psi).

***\*IT IS IMPORTANT TO NOT USE ANY CLEANERS ON THE SUPERNANO-WEB MEDIA OR APPLY ANY OIL!!!***

**NOTE: DISCONNECT BATTERY BEFORE INSTALLATION!!!**

# Instruction Manual P/N:EVO7202



**1.** Stock intake system shown.



**2.** Use a 7mm nut driver to remove the four air vent screws. Remove the air vent from the engine bay for now.



**3.** Loosen the clamps on the stock intake tube using 8mm nut driver. Disconnect the crank case lines on intake tube.



**4.** Now pull out the intake tube out of vehicle.



**5.** Pull back lines away from the air box. Disconnect MAF sensor harness.




**6.** Loosen the two 10mm bolts holding in air box.




**7.** Carefully remove the air box out of the vehicle.




**8.** Loosen the 2 screws holding in the MAF sensor, remove the sensor.



**9.** Install the straight hose with clamps to throttle body. Tighten the clamp on throttle body only.



**10.** Remove the factory grommets and washer-spacer out of air box. These will be used on new injen air box. Keep same configuration.



**11.** Now install the grommets and washer-spacers to the new injen airbox.



**12.** Install the Filter Minder plug into the Filter Minder hole located on top of the air box assembly.


# Instruction Manual P/N:EVO7202



**13.** Place the filter onto the Injen plenum and then secure the clamp



**14.** Install the plenum assembly into the lower air box.




**15.** Place the Injen plenum onto the Injen lower air box assembly and use 4-M6X20 bolts and rubberized washers secure the plenum to the lower air box.




**16.** Now install the MAF sensor into the plenum. Secure using provided M4 screws.




**17.** Install the airbox assembly to the factory position.




**18.** Secure the air box using factory bolts. Tighten and secure using 10mm socket and ratchet.



**19.** Re-connect MAF sensor harness.



**20.** Install the intake tube. Attach the with clamps to the intake tube. Position for best fit.



**21.** Now secure and tighten all clamps using 8mm nut driver.



**22.** Reconnect both crank case fittings. Some models only have 1 crank case line. Remove the fitting and use the supplied 3/8"-16 Hex bolt to block the fitting if not used. Secure threads with Loctite



**23.** Re-install air vent and secure.



Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose. **Note: Check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.**

## Test Drive:

1. With the transmission in neutral or park and the parking brake engaged, start the engine. Listen for air leaks or odd noises. If air leaks are detected, secure hoses and connections. For any odd noises, inspect entire system for cause and adjust intake as needed. The Injen intake will function identically to the factory system but will be louder and more powerful.
2. Perform a road test. Listen for odd noises or rattles and fix as necessary.
3. If there are no issues, continue to enjoy your added performance from the Injen performance Intake kit.
4. Injen Technology recommends you periodically check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.

1. Upon completion of the installation, reconnect the negative battery terminal before you start the engine.
  2. Align the entire intake system for the best possible fit. Once the intake has been properly fitted continue to tighten all nuts, bolts and clamps.
  3. Periodically, recheck the alignment of the intake system and make sure there is proper clearance around and along the length of the intake. Failure to follow proper maintenance procedures may cause damage to the intake and will void the warranty.
  4. Start the engine and listen carefully for any odd noises, rattles and/or air leaks prior to taking it for a test drive. If any problems arise go back and check the vacuum lines, hoses and clamps that maybe causing leaks or rattles and correct the problem.
  5. Check the filter for excessive dirt build up. Clean or replace the filter with an original Injen filter (can be bought on-line at "injenonline.com").
- Congratulations! You have just completed the installation of the best intake system sold on the market. Enjoy the added power and performance of your new intake system.