




# INSTALLATION INSTRUCTIONS

Direct Fit Catalytic Converter

**MAKE:** Porsche  
**MODEL:** Carrera 911  
**YEAR:** 85-89  
**ENGINE:** H6-3.2L

47-46401



### EMISSIONS DISCLAIMER

This product is EPA compliant, not for sale or use on vehicles certified for the state of California. Consult your state or local authority for any additional clarification. Replacement of catalytic converters (if equipped) is allowed only under the following conditions: 1) It is missing or stolen; 2) It is damaged or lead poisoned as determined by a state or local inspection facility; or 3) It is outside of the manufacturers warranty period (consult your owner's manual), if none stated, 5 years or 50,000 miles.

<i>Item</i>	<i>Description</i>	<i>Part Number</i>	<i>Quantity</i>
1	Direct Fit Catalytic Converter	05-144904	1

**aFe POWER recommends professional installation on this product.** Thoroughly inspect the aFe POWER exhaust system to make sure there is no damage from shipping (if damage is noted, immediately contact aFe POWER customer service). Allow time for your vehicle to cool down prior to installation. When working on your vehicle proceed with caution. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

Install band clamps to proper torque specifications of 40-45 ft-lb.

**1**





## INSTALLATION INSTRUCTIONS

Direct Fit Catalytic Converter

**MAKE:** Porsche  
**MODEL:** Carrera 911  
**YEAR:** 85-89  
**ENGINE:** H6-3.2L

47-46401

1. **(Read instructions prior to installation.)** It is recommended to not fully tighten the system until it has been fully installed. Leave loose for adjustability.
2. Secure vehicle on jack stands (refer to your manual for specified jack stand positions).
3. Secure the stock exhaust with jack/stands.
4. Remove the O.E. heat shield and the O2 sensor.
5. Remove O.E. Catalytic Converter.
6. Replace O.E. Gaskets if necessary.
7. Using the O.E. hardware, install the aFe POWER direct fit catalytic converter.
8. Reinstall O2 sensor and heat shield.
9. Ensure that all the components of the aFe POWER system are aligned and are at a safe clearance from all wires, hoses, brake lines, body parts, and tires.
10. Start the vehicle and check for any leaks. If any leaks are found, determine cause and repair as necessary.
11. Remove vehicle from jacks stands.
12. It is recommended to re-tighten all clamps and hardware after 50-100 miles.