

advanced FLOW engineering Instruction Manual P/N: 49-36306

Make: BMW Model: 335i E90/E92 Year: 2011-2012 Engine: L6-3.0L (t)





- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
А	1	Muffler/Tailpipe Left	05-45376
В	1	Muffler/Tailpipe Right	05-45397
С	1	Midpipe #1, Left	05-45392
D	1	Midpipe #1, Right	05-45393
Е	1	Midpipe #2, Left	05-45394
F	1	Midpipe #2, Right	05-45395
G	1	Adjustable Hanger #EU, Left	05-41203
Н	1	Adjustable Hanger #EV, Right	05-41204
I	4	Band Clamps	05-41160
J	16	Spacers	03-50211
K	8	M8 Button Head Screw	03-50111
М	8	Washer, Flat, M8	03-50065
N	2	Screw, 1/4-20x3/4	03-50100
0	2	Nut, 1/4-20	03-50073
Р	2	Washer, Flat, M6	03-50070
Q	1	Plug, Vacuum line	03-50201


Installation will require the following tools:

T-50 torx bit, 5mm hex key, Ratchet, 3/8", 7/16", 12mm, 13mm, 15mm and 18mm sockets and wrenches.

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.








Refer to Figure A for step 1


1. Loosen the (4) flange nuts but do not remove completely at this time.



Refer to Figure B for step 2


2. Remove the 13mm hex head screws & brackets at rear of transmission (Note: This will not be reused due to larger tube size.)





Refer to Figure C for step 3

3. Remove the (8) T-50 Torx screws 2 and Connecting Support plate. 3



Refer to Figure D for steps 4-5


- 4. Place a support stand under the rear of the exhaust to support its weight.
- 5. Remove the hangers from the Differential area.





Refer to Figure E for step 6


6. Remove the hangers from the front of the mufflers.



Refer to Figure F for step 7-8

- 7. Disconnect the vacuum hose from the left exhaust muffler outlet actuator and plug the hose with the supplied vacuum plug and tuck the hose out of the way. (see fig. F1)
- 8. Remove the hangers from the rear of the mufflers while making sure the exhaust system is safely supported.





Refer to Figure G for step 9

9. With an assistant remove the (4) flange nuts (save for later use) and lower the complete exhaust system. Replace the flange gaskets if they are no longer serviceable.

Note: You will not be reusing the flange bracket.



Refer to Figure H for step 10

10. Install the right side exhaust starting from the flange rearward (Midpipe #1). Reconnect using new gaskets or the originals if still serviceable. The use of anti-seize is recommended on the flange studs. (Do not tighten the flange nuts at this time.)





Refer to Figure I for step 11

11. Install Midpipe #2 using a band clamp and connect its isolation mount. (Do not tighten at this time.)



Refer to Figure J for step 12

12. Install Muffler/Tailpipe assembly using a band clamp and connect its front and rear isolation mounts. The rearmost mount is a 2-piece adjustable bracket (see fig J1) that will use Hanger #EV. (Do not tighten at this time.)





Refer to Figure K for step 13

13. The front flange mount nuts can now be tightened. The tubes can be positioned and the band clamps can now be tightened.



Refer to Figure L for steps 14 & 16

- 14. The left side can now be installed repeating steps 10-13 and using adjustable Hanger #EU.
- 16. Adjust both rearmost hangers to center the tips in the bumper cutouts.





Refer to Figure M for step 15

15. Install the Connecting Support plate using the button head screws (8) and aluminum spacers (16) provided in kit. Your installation is complete.

Note: It is suggested that all components be retightened after approximately 150 miles.

Page left blank intentionally



aFe Black Polo



P/N: 40-31209 M 40-31210 L 40-31211 XL 40-31212 2XL 40-31213 3XL



P/N: 40-10090

aFe Tan Polo



P/N: 40-31214 M 40-31215 L 40-31216 XL 40-31217 2XL 40-31218 3XL

aFe Lic. Plate Frame



P/N: 40-10097

aFe Power Hat



P/N: 40-10043

aFe Key Chain

P/N: 40-10109

To purchase any of the items above, view airflow charts, dyno graphs, photos, and video; please go to aFepower.com.

Warranty

General Terms:

- aFe warrants their products to be free from manufacturer's defects due to workmanship and material.
- This warranty applies only to the original purchaser of the product and is non-transferrable.
- Proof of purchase of the aFe product is required for all warranty claims.
- Warranty is valid provided aFe instructions for installation and/or cleaning were properly followed.
- Proper maintenance with regular inspections of product is required to insure warranty coverage.
- Damage due to improper installation, abuse, unauthorized repair or alteration is not warranted.
- Incidental or consequential damages or cost, including installation and removal of part, incurred due to failure of aFe product is not covered under this warranty.
- All warranty is limited to the repair and/or replacement of the aFe part. To request Return Goods Authorization
 ("RGA"), email RGA@afepower.com or call (951)493-7100. Upon receipt of the RGA, you must return the product
 to the address provided in the RGA, freight prepaid and accompanied with a dated proof of purchase and the RGA.
 Upon receipt of the defective product and upon verification of proof of purchase, aFe will either repair or replace the
 defective product within a reasonable time, not to exceed thirty days.

Product Category	P/N Prefix	Warranty duration
Direct OE Replacement Filters	10, 11, 30, 31, 71, 73	Life of the vehicle
Racing Filters	18	1 year
Universal	21, 24, 72,TF	2 years
Air Intake Systems	50, 51, 54, 55, 75,TR.TA,TL	2 years
Exhaust Systems	49	2 years
Intercoolers & Intercooler Tubes	46-2	2 years
Intake Manifolds	46-1	2 years
Differential Cover	46-7	Life of the vehicle
Exhaust Manifolds	46	2 years
Throttle Body Spacers	46-3	2 years
Fluid Filters	44	90 days
Pre-Filters	28	2 years
Heavy Duty OE Replacement	70	2 years
PowerSports OE Replacement	81, 87	2 years
PowerSports Intake Systems	85	2 years

No other warranty expressed or implied applies nor is any person or advanced FLOW engineering authorized to assume any other warranty. Some States do not allow the exclusion or limitation of incidental or consequential damages or do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

Page 19



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879
TEL: 951.493.7100 • TECH: 951.493.7100 x23
E-Mail:Tech@aFepower.com