


# S5602

2014-UP PORSCHE MACAN  
GTS/S/TURBO, 2.5", AXLE BACK, MUFFLER  
BYPASS

# MBRP®



ITEM	DESCRIPTION	QTY.
1	PASSENGER-SIDE TAIL PIPE	1
2	DRIVER-SIDE TAIL PIPE	1
3	2.5" CLAMP	4
4	PASSENGER-SIDE TIP	1
5	DRIVER-SIDE TIP	1

## PLEASE READ BEFORE STARTING INSTALLATION

While MBRP has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following before removal of the factory exhaust:

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.

# MBRP



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

## Removal of stock system:

1. Apply a penetrating lubricant liberally to all hangers, hardware and rubber isolators.
2. Cut the factory Driver-Side muffler 3" from the welded bracket on the y-pipe.

**Refer to Figure 1.**

3. Cut the factory Passenger-Side muffler 3" from the end of the bend.

**Refer to Figure 2.**

4. Remove factory hanger brackets and remove the factory mufflers

## Installation of MBRP Performance Exhaust:

1. Install the factory hanger bracket onto the **Passenger-Side Tail Pipe** hanger. Repeat for the driver-side

**Refer to Figure 3.**

2. Install the **Passenger-Side Tail Pipe** onto the factory y-pipe securing it with one of the supplied **2.5" Band Clamps**. Repeat for the driver-side

**Refer to Figure 4.**

3. Re-install the factory hanger brackets.

4. Using a **2.5" Clamp**, loosely install the **Passenger-Side Tip**. Orient the **2.5" Clamp** so that it is easily tightened, yet tucked up out of sight. Repeat for driver-side.

**Refer to Figure 5.**

5. Tighten all hardware and clamps, starting at the front and working rearward to secure the system. Check along the full length of the exhaust system to ensure there is adequate clearance for fuel lines, vent lines, brake lines, frame, bodywork, suspension and any wiring, etc. If there is any interference detected, relocate or adjust to provide adequate clearance. Ensure all clamp connections are secure and components are unable to rotate or slide. Band clamps require approximately 45 lb-ft (60 N-m) of torque. Verify clearances, system security and band clamp torque after 30-60 miles (50-100 km) of driving.



**Congratulations!** You are ready to begin experiencing the improved power, sound and driving experience of your **MBRP** performance exhaust system. We know you will enjoy your purchase.